

FINNISH SAUNA JF0120


Specifications and assembly instructions

SPECIFICATIONS



Model	JF0120
Dimensions	1200x1050x1900 mm
Number of persons	2
Wood	Finnish pine, 48 mm
Glass	Transparent, hardened, 6 mm
Courses	Stainless steel
Control	Buttons on the stove
Operating time	Up to 90 min
Temperature	Up to 90 °C
Ventilation	Yes
Connectivity	/
Lighting	LED RGB central light
Oven	3 kW, with thermostat, timer and volcanic stone
Connection	Schuko socket 230 V, 50 Hz, 16 A fuse
Weight	161 kg

COMPONENTS



1 Cover plate 6 Right side
2 Ceiling panel 7 Bench
3 Backplate 8 Stove
4 Left side 9 Stove frame

5 Front panel with glass panels 10 Bottom

RECOMMENDED TOOLS



ASSEMBLY TIPS

Please remove the transport packaging and check that your sauna has been delivered complete and undamaged before starting assembly. At least two people are needed to assemble the sauna.



ASSEMBLY STEPS







3. Left side - fasten the buckles



1. Bottom

4. Right side - fasten the buckles



5. Bench



6. Front side with glass panels - fasten the buckles



7. Ceiling panel



8. Screw the ceiling panel to the upper part of the side panels.




9. Cover plate





10. Furnace and furnace frame

Installing the outer buckle







Installation of hinges, handle and cover



 Install the hinges - the soft parts should be next to the glass, on the inside of the hinges



2. Install the handle, screws from the inside of the sauna.



3. Install the cover plate

WIRING DIAGRAM

FOR SAUNAS: JFO120, JFO150

Single-phase connection

Finnish stove remove the information plate to enable connection L1 LI N L1 AC OUT OVERHEAT SWITCH NC 105°C LT HOUSE SUPPLY WIRE 3 x 2,5 mm² 16A fuse or WIRE WITH SCHUKO PLUG

Three-phase connection

